

# LABORATORIO DI REALTÀ AUMENTATA


Claudio Piciarelli

Università degli Studi di Udine  
Corso di Laurea in Scienze e Tecnologie Multimediali



# Project: marker detection

# Architecture of an AR system



# STM AR: marker detection

---


- We already know how to acquire images from a webcam
- We will now process these images to detect fiducial markers
- library used: **JSARToolKit**

# JSARToolKit

- ❑ Open source library for fiducial marker detection and tracking
- ❑ Port of the Flash FLARToolkit library...
- ❑ Which was a port of the Java NyARToolkit lib...
- ❑ Which was a port of the C ARToolKit lib


# JSARToolKit

- How it works
  - ▣ Detection on a single image




# JSARToolKit

- How it works
  - ▣ Detection on a video






# JSARToolKit internals







# Thresholding



# Detection



# Matrix computation



The screenshot shows a web browser's developer console. At the top, there's a tab labeled 'Console'. Below it, a toolbar contains a mute icon, a filter icon, the text '<top frame>', a dropdown arrow, and a checkbox labeled 'Preserve log'. The main area of the console displays a log entry from 'lez07 01 - jsartoolkit.html:55'. The entry is a JavaScript object with the following properties: 'error' (1.3432114273931062), 'm00' (0.8410054217992563), 'm01' (0.5186782209523433), 'm02' (-0.15389211680254275), 'm03' (101.60648563127894), 'm10' (0.34185903541858653), 'm11' (-0.729921277462959), 'm12' (-0.5919014517717588), 'm13' (-103.38625777471728), 'm20' (-0.4193355224720759), 'm21' (0.4451829195022583), 'm22' (-0.7911825881403843), and 'm23' (468.6866097666396). The object also has a '\_\_proto\_\_' property pointing to an 'Object'. A blue arrow icon is visible next to the object's name 'g'.

```
lez07 01 - jsartoolkit.html:55
▼ g {error: 1.3432114273931062, m00: 0.8410054217992563, m01:
0.5186782209523433, m02: -0.15389211680254275, m03:
101.60648563127894...} ⓘ
  error: 1.3432114273931062
  has_value: true
  m00: 0.8410054217992563
  m01: 0.5186782209523433
  m02: -0.15389211680254275
  m03: 101.60648563127894
  m10: 0.34185903541858653
  m11: -0.729921277462959
  m12: -0.5919014517717588
  m13: -103.38625777471728
  m20: -0.4193355224720759
  m21: 0.4451829195022583
  m22: -0.7911825881403843
  m23: 468.6866097666396
  __proto__: Object
```

# Getting JSARToolKit

- Download it from the elearning page
- ...or download it from:
  - ▣ `https://github.com/kig/JSARToolKit`
- Use the stripped down version:
  - ▣ `JSARToolKit.min.js`

# Markers

- JSARToolKit supports its own fiducial markers, which encode numbers
- You can find markers for the numbers 0 to 99 in the JSARToolKit zip you just downloaded
  - ▣ Folder: demos/markers
- These are .png files (rename them if you can't open)
- Print them, or keep one on screen, or use the marker.webm video file...

# Including JSARToolKit in our project

- ❑ Open the project of the previous lesson
- ❑ Import the javascript code with:

```
<script src="JSARToolKit.min.js"></script>
```

- ❑ Copy the JSARToolKit.min.js file in the same folder of your html page!

# Adding a canvas

- As mentioned before, JSARToolKit works on canvas, not videos
- Add a canvas to the HTML page:

```
<body>  
  <video autoplay id="myvideo"></video>  
  <canvas id="mycanvas"></canvas>  
</body>
```

# Wait for the video to be ready

- We must wait the video is loaded (or at least its *metadata*) before we can start processing it
- Metadata contains duration, dimensions, subtitles tracks etc...
- We listen for the `loadedmetadata` event
- For a full list of video events, see:


[http://www.w3schools.com/tags/ref\\_av\\_dom.asp](http://www.w3schools.com/tags/ref_av_dom.asp)



# Event listener

- After the call to `getUserMedia`, set the listener

```
window.onload = function() {  
    // connect to webcam  
    var video = document.getElementById("myvideo");  
    var constraints = {audio: false, video: true};  
    navigator.mediaDevices.getUserMedia(constraints)  
        .then(function(stream) {  
            video.srcObject = stream;  
        })  
        .catch(function(err) {  
            alert(err.name + ": " + err.message);  
            video.src = "marker.webm";  
        });  
    video.onloadedmetadata = start_detection;  
}
```



# Listening to an event

## □ Two ways:

```
video.onloadedmetadata = start_detection;  
video.addEventListener("loadedmetadata", start_detection);
```

In the first case, be careful not to write

```
video.onloadedmetadata = start_detection();
```

This would execute the function, rather than hooking it to an event!

# Detecting video size

- What's the difference between `.width`, `.clientWidth` and `.videoWidth`? (the same for height)

```
function start_detection(event){  
    var video = document.getElementById("myvideo");  
    console.log("size: ", video.width, video.height);  
    console.log("client size: ", video.clientWidth, video.clientHeight);  
    console.log("video size: ", video.videoWidth, video.videoHeight);  
}
```


## Output:

```
size: 0 0  
client size: 640 480  
video size: 640 480
```

# Sizes

- width is the size specified in the HTML tag, if any. It can be modified to resize the video. If not specified, it is 0
- videoWidth is the original video width (read-only)
- clientWidth is the width at which the video is currently shown in the web page (read-only)

# Sizes



```
function start_detection(event) {  
    var video = document.getElementById("myvideo");  
    video.width = 300;  
    console.log("size: ", video.width, video.height);  
    console.log("client size: ", video.clientWidth, video.clientHeight);  
    console.log("video size: ", video.videoWidth, video.videoHeight);  
}
```

## Output:

```
size: 300 0  
client size: 300 225  
video size: 640 480
```

# Video to canvas

- JSARToolKit works on canvas, thus we must copy the video frames in the canvas

```
function start_detection(event) {  
    var video = document.getElementById("myvideo");  
    var canvas = document.getElementById("mycanvas");  
    var ctx = canvas.getContext("2d");  
    canvas.width = video.clientWidth;  
    canvas.height = video.clientHeight;  
    ctx.drawImage(video, 0, 0, canvas.width, canvas.height);  
}
```

- Assign the canvas the same size of displayed video
- Copy the image **and rescale it**
- Check what happens with just

```
ctx.drawImage(video, 0, 0);
```

# Canvas update

- The canvas must be updated at each frame
- Try the `timeUpdate` video event

```
function start_detection(event) {  
    var video = document.getElementById("myvideo");  
    var canvas = document.getElementById("mycanvas");  
    var ctx = canvas.getContext("2d");  
    canvas.width = video.clientWidth;  
    canvas.height = video.clientHeight;  
  
    video.ontimeupdate = function() {  
        ctx.drawImage(video, 0, 0, canvas.width, canvas.height);  
    }  
}
```

# Canvas update

- `ontimeupdate`: poor performance
- Alternative solution

```
setInterval(function() {  
    ctx.drawImage(video, 0, 0, canvas.width, canvas.height);  
}, 40);
```

- First parameter: function to be called every n milliseconds

```
setInterval(function() {  
    ctx.drawImage(video, 0, 0, canvas.width, canvas.height);  
}, 40);
```


- Second parameters: the time interval (why 40 ms?)

```
setInterval(function() {  
    ctx.drawImage(video, 0, 0, canvas.width, canvas.height);  
}, 40);
```



# Hide the video

- At this point we have two copies of the video on screen. We can hide the original video and show only the canvas



```
function start_detection(event) {  
    var video = document.getElementById("myvideo");  
    var canvas = document.getElementById("mycanvas");  
    var ctx = canvas.getContext("2d");  
    canvas.width = video.clientWidth;  
    canvas.height = video.clientHeight;  
    video.style.display = "none";  
  
    setInterval(function() {  
        ctx.drawImage(video, 0, 0, canvas.width, canvas.height);  
    }, 40);  
}
```

# Setting up JSARToolKit

- JSARToolKit uses raster objects to read data from canvas

```
function start_detection(event) {  
    (...)  
    // setup JSARToolKit  
    var raster = new NyARRgbRaster_Canvas2D(canvas);
```

# Setting up JSARToolKit

- Params are used to properly initialize the camera model with the correct aspect ratio

```
function start_detection(event) {  
    (...)  
    // setup JSARToolKit  
    var raster = new NyARRgbRaster_Canvas2D(canvas);  
    var param = new FLARParam(canvas.width, canvas.height);
```

# Setting up JSARToolKit

- The detector is the JSARToolKit core. It detects multiple markers simultaneously

```
function start_detection(event) {  
    (...)  
    // setup JSARToolKit  
    var raster = new NyARRgbRaster_Canvas2D(canvas);  
    var param = new FLARParam(canvas.width, canvas.height);  
    var detector = new FLARMultiIdMarkerDetector(param, 76);
```

- 76 is the real size of the markers to be detected, in millimeters

This real-world size is important for detection. Can you figure out why?

# Setting up JSARToolKit

- Tells the detector to continuously track markers across multiple frames

```
function start_detection(event) {  
    (...)  
    // setup JSARToolKit  
    var raster = new NyARRgbRaster_Canvas2D(canvas);  
    var param = new FLARParam(canvas.width, canvas.height);  
    var detector = new FLARMultiIdMarkerDetector(param, 76);  
    detector.setContinueMode(true);  
}
```

# Processing each frame

- Now process each frame. We set `canvas.changed = true` to tell JSARToolKit that the canvas has changed and must be processed

```
setInterval(function() {  
    ctx.drawImage(video, 0, 0, canvas.width, canvas.height);  
    canvas.changed = true;  
}, 40);
```

# Processing each frame

- Run the detector. The second parameter (128) is a **threshold** (more about this later)
- Returns the number of detected markers

```
setInterval(function() {  
    ctx.drawImage(video, 0, 0, canvas.width, canvas.height);  
    canvas.changed = true;  
    var markerCount = detector.detectMarkerLite(raster, 128);  
}, 40);
```

# Processing each frame

- If at least a marker has been detected, get the *transformation matrix* of the first one

```
setInterval(function() {  
    ctx.drawImage(video, 0, 0, canvas.width, canvas.height);  
    canvas.changed = true;  
    var markerCount = detector.detectMarkerLite(raster, 128);  
    if(markerCount > 0) {  
        var tmat = new NyARTransMatResult();  
        detector.getTransformMatrix(0, tmat);  
        console.log(tmat);  
    }  
}, 40);
```




# Final start\_detection() code

```
function start_detection(event) {  
    // canvas setup  
    var video = document.getElementById("myvideo");  
    var canvas = document.getElementById("mycanvas");  
    var ctx = canvas.getContext("2d");  
    canvas.width = video.clientWidth;  
    canvas.height = video.clientHeight;  
    video.style.display = "none";  
  
    // JSARToolKit setup  
    var raster = new NyARRgbRaster_Canvas2D(canvas);  
    var param = new FLARParam(canvas.width, canvas.height);  
    var detector = new FLARMultiIdMarkerDetector(param, 76);  
    detector.setContinueMode(true);  
  
    // frame loop  
    setInterval(function() {  
        ctx.drawImage(video, 0, 0, canvas.width, canvas.height);  
        canvas.changed = true;  
        var markerCount = detector.detectMarkerLite(raster, 128);  
        if(markerCount > 0) {  
            var tmat = new NyARTransMatResult();  
            detector.getTransformMatrix(0, tmat);  
            console.log(tmat);  
        }  
    }, 40);  
}
```



# Results



The screenshot shows a web browser's developer console. At the top, there's a tab labeled 'Console'. Below it, a toolbar contains a mute icon, a filter icon, the text '<top frame>', a dropdown arrow, and a checkbox labeled 'Preserve log'. The main area of the console displays a log entry from 'lez07 01 - jsartoolkit.html:55'. The entry is a log statement for a variable 'g' containing an object with several properties. The object is expanded, showing its internal structure with properties like 'error', 'has\_value', and 'm00' through 'm23'. The values are displayed in a color-coded format: error in red, has\_value in blue, and numerical values in purple. The entry ends with '\_\_\_proto\_\_: Object'.

```
lez07 01 - jsartoolkit.html:55
▼ g {error: 1.3432114273931062, m00: 0.8410054217992563, m01:
0.5186782209523433, m02: -0.15389211680254275, m03:
101.60648563127894...} ⓘ
  error: 1.3432114273931062
  has_value: true
  m00: 0.8410054217992563
  m01: 0.5186782209523433
  m02: -0.15389211680254275
  m03: 101.60648563127894
  m10: 0.34185903541858653
  m11: -0.729921277462959
  m12: -0.5919014517717588
  m13: -103.38625777471728
  m20: -0.4193355224720759
  m21: 0.4451829195022583
  m22: -0.7911825881403843
  m23: 468.6866097666396
  ► __proto__: Object
```

# Understanding the results

- The transformation matrix represents the marker 3D position respect to the camera
- We will use this data to align a 3D model with the marker
- More info on transformation matrices in the next lessons

# Extra: debug canvas

- JSARToolKit allows the visualization of a debug canvas where you can see the internal processing
- Add a canvas with `id="debugCanvas"` in your HTML code (must have this name!)
- Add this javascript code after JSARToolKit initialization

```
// JSARToolKit debugging
var dcanvas = document.getElementById("debugCanvas");
dcanvas.width = canvas.width;
dcanvas.height = canvas.height;
DEBUG = true;
```

# Extra: adjusting the threshold

- Threshold values are in the range 0 – 255
- The final result is heavily influenced by the choice of threshold
- Homework: add a slider to your HTML page to change the threshold dynamically
  - ▣ Hint: learn to use `dat.GUI`:
  - ▣ <https://github.com/dataarts/dat.gui>

# Extra: extracting marker IDs

- Each marker has its own ID encoded in the marker shape (numbers from 0 to 99)
- Extracting the marker ID could be useful (e.g. in a multi-marker system)
- Check the code:

`http://www.html5rocks.com/en/tutorials/webgl/jsartoolkit\_webrtc/`